# HI 151-00 Range -50.0 to +220°C Resolution 0.1°C (-50.0 to 199.9°C), 1°C (200 to 220°C) Accuracy ±0.4°C±1 digit (-20.0 to 90.0°C); (@25°C/77°F) ±1% f.s. ±1 digit (outside) Typical EMC Deviation ±0.3°C

UI 151 (

HI 151-01

 $\pm 1\%$  f.s.  $\pm 1$  digit (outside)

 Range
 -58.0 to  $+428^{\circ}$ F

 Resolution
 0.1°F (-58.0 to 199.9°F), 1°F (200 to 428°F)

 Accuracy
  $\pm 0.8^{\circ}$ F  $\pm 1$  digit (-4.0 to 194.0°F);

Typical EMC Deviation ±0.6°F

**Common specifications** 

Probe	Stainless steel sharp probe (117 x 3.5 mm)
Calibration	In factory only
Battery Type/Li	fe 1x1.5V AA / 25.000 hours of continuous use
Auto-off	after 5 minutes
Dimensions	165x50x20 mm (6.5 x 2.0 x 0.8")
Weight	100 g (3.6 oz)

## WARRANTY

(@25°C/77°F)

HI 151-00 and HI 151-01 are warranted for one year against defects in workmanship and materials when used for its intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge.

Damages due to accident, misuse, tampering or lack of prescribed maintenance are not covered. If service is required, contact the dealer from whom you purchased the instrument. If under warranty, report the model number, date of purchase, serial number and the nature of the failure. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the instrument is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization Number from the Customer Service department and then send it with shipment costs prepaid. When shipping any instrument, make sure it is properly packaged for complete protection.


All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner, Hanna Instruments Inc., Woonsocket, Rhode Island, 02895 , USA.

#### Recommendations for Users

Before using these products, make sure that they are entirely suitable for the environment in which they are used. Operation of these instruments in residential areas could cause unacceptable interferences to radio and TV equipment. Any variation introduced by the user to the supplied equipment may depade the instrument's EML performance. To avoid deterical shock, do not use these instruments when voltages at the measurement surface exceed 24 VAC  $\alpha$  60 VDC. To avoid damages or burns, do not perform any measurement microwave overs.

# Checktemp 4 (HI 151-00 and HI 151-01)

# Rugged Folding Thermometers







**Checktern**: 4 are high accuracy thermometers, easy to use, offering quick and precise measurements.

**Checklemp 4** is the ideal solution for food applications. The sharp stainless steel probe is specially designed for penetration of cooked as well as on semi-frozen food. In addition, the probe nestles in the casing to make the thermometers truly portable.

**Checktemp.** 4 is equipped with the Cal-Check feature. Every time the meter is turned on, it performs a self test of its calibration status and provides a visual confirmation.


Two models are available:

- HI 151-00 measures temperature in °C
- HI 151-01 measures temperature in °F.

The meters are calibrated using four temperature points.

# TAKING MEASUREMENTS

- Turn the meter on by simply opening the probe.
- Introduce the probe in the sample. For ideal measurement an immersion level of 4 cm (11/2") is recommended. Wait for a few seconds for the reading to stabilize and for the temperature value be displayed on the LCD.
- After 5 minutes, the meter switches itself off. To restart, close and open the probe again.
- Turn the meter off by closing the probe and returning it to its original position.



Note: Clean the probe after use and before storing it.

# CALIBRATION SELF CHECK


Every time the meter is switched on, it checks its calibration status.

If the LCD displays "CAL" and then -0- the meter is calibrated and in a few seconds it will be ready for normal operating mode.

If the meter is not calibrated or the battery level is too low, the LCD displays "Err". First replace the battery as described below; if the "Err" warning message is still displayed, contact your dealer or your nearest Hanna Service Center for recalibration.

### BATTERY REPLACEMENT

"Err" warning message, variations in readings or fading display can indicate a low battery level. Remove the cover of the battery compartment on the back side and replace the 1.5V AA battery while paying attention to its polarity.



# CE DECLARATION OF CONFORMITY

